












FUSIBILI A LAMA MIDI CON LED
MIDI BLADE FUSES WITH LED
FUSIBLES ENFICHABLES MIDI AVEC LED
MIDI FLACHSICHERUNGEN MIT LED



FUSIBILI A LAMA MIDI MIDI BLADE FUSES FUSIBLES ENFICHABLES MIDI MIDI FLACHSICHERUNGEN	CORRENTE NOMINALE RATED CURRENT COURANT NOMINALE NENNSTROM	COLORE COLOR COULEUR FARBE	CODICE CODE CODE TEILE Nr.
	2A	Arancione Orange Orange Orange	102A-LED
	3A	Viola Violet Violet Violett	103A-LED
	4A	Rosa Pink Rose Rosa	104A-LED
	5A	Beige Light Brown Marron Clair Beige	105A-LED
	7,5A	Marrone Brown Marron Braun	175A-LED
	10A	Rosso Red Rouge Rot	110A-LED
	15A	Blu Blue Bleu Blau	115A-LED
	20A	Giallo Yellow Jaune Gelb	120A-LED
	25A	Neutro Neutral Neutre Neutral	125A-LED
	30A	Verde Green Vert Grün	130A-LED